



# MOUNTING TEMPLATE



Four Stainless Steel 5/16" Button Head Socket Cap Screws with Nyloc Nuts, Fender Washers and/or Backing Plates should be used.

Center punch each hole. Start with a small drill bit and increase bit size to 5/16". It is good practice to use tape on the surface to be drilled then drill the hole through the tape.

This will avoid scratching / chipping of the surrounding surface.

Apply 3M 5200 Sealant to seal drilled holes and the bottom of the mounting plates.

*If printing this template, measure for accuracy.*

