



# MOUNTING TEMPLATE



**Four Stainless Steel 5/16" or 1/4" Button Head Socket Cap Screws with Nylock Nuts, Fender Washers and/or Backing Plates, should be used. Center punch each hole. Start with a small drill bit and increase bit size. It is good practice to use tape on the surface to be drilled then drill the hole through the tape, this will avoid scratching/chipping of the surrounding surface. Apply 3M 5200, or equivalent, to seal drilled holes and the bottom of the mount plates.**

**If printing this template, print "Actual Size" on a legal size sheet of paper and measure for accuracy.**

