

DECK PLATE INSTALLATION

Planning the installation - Deck Plate Install:

After determining where to place your Chocks or SUP Rack start with a small drill bit and increase bit size to 3/4" for the center hole. The three screw holes should be drilled for #10 screws, 5/32" / .156". It is good practice to use tape on the surface to be drilled then drill the hole through the tape, this will avoid scratching/chipping of the surrounding surface. Generously apply 3M 5200 sealant to seal drilled holes and the bottom of the decking plates.

Measure twice, drill once!



Tie downs must be used when underway!

